


Team: UmidaAG.com



We taken our Aquifer Pipe used for subsurface irrigation and groundwater recharging and flip it upside down.

6 Inch Aquifer Pipe facing up

Installed 1 to 2 feet below the body of waters floor, the sand ,rocks and sediment filter the water from aquatic life before entering the Aquifer Pipe



6 Inch Aquifer Pipe facing

Water enters from 1/4 holes in the top of the "V" channel .

Then flows in this cavity to a sump basin

